

Town & Country Installation Guide

Decorative installation only.

Installation brackets.

1. Lay one installation bracket on the bottom of the shutter and mark the locations of each hole. Using a fine drill bit suitable for the screws supplied drill the locating holes. Do the same for the top edge.
2. Position the shutter on the wall so that it is parallel with the reveal edge and mark the location on the wall at the bottom corners. Now position the bottom bracket on to the wall to align with the marks that you made. Make new marks for the holes in the wall through the slots in the bracket. The slots are to allow for movement (contraction & expansion) as well as fine positioning. Drill the holes in the wall.
3. Place the wall anchors in the holes and screw home. As it is this bottom bracket that will be taking the weight of the shutter make sure that you have a firm and secure fixing.
4. Sit the shutter onto the bracket and adjust so that the shutter is parallel with the window reveal. Now place the top bracket on the shutter and mark the location on the wall. Remove the shutter and reposition the top bracket with the marks that you made. Mark the locations for the holes into the wall and drill suitable holes for the wall anchors to be inserted. Insert wall anchors and screw home the screws provided. It is important that the top bracket is not over tightened and is allowed to move freely along the slots. This is to allow for expansion and contraction of the shutters.
5. Reposition the shutter so that the pre-drilled holes that you made in the shutter line up with the holes in the brackets. Use the smaller screws to screw into the shutter from above and below having first applied the tiniest amount of silicon sealer to the tip of each screw. Do not apply too much sealant as this will create a mess and do not over tighten the screws.

Face fixed screws.

1. Drill a suitably sized hole in each corner of the shutter using an HSS drill bit. The hole must be big enough to allow the shank of the screw (#12 / 3/4" stainless steel screws supplied) to pass through but not the head.
2. Position the shutter on the wall and mark the location of each hole in the shutter onto the wall.
3. Using a no. 8 (1/4 inch) masonry drill bit drill the holes in the wall and locate the wall anchors supplied. Make sure that the holes are deep enough for the screws.
4. For taller shutters over 50" we recommend the option of using 6 fixings per shutter as there may be a slight degree of bow otherwise.
5. Position the shutter and screw into the wall anchors making sure not to over tighten the screws (we suggest that you leave up to 1mm clearance), as the shutter needs some clearance to expand and contract.
6. Touch in the heads of the screws with the dual action touch up pencil supplied. There is a brush attachment and a needlepoint applicator for small chips.
7. Two pack paint finishes require a hardener (supplied). Mix the hardener with the paint (1 part to 4 parts paint). Do not mix more than you require, as the paint, once mixed with hardener, will set in about 1 hour. Use a teaspoon or the pipette supplied to measure out the quantities and apply with a small brush. The brush can only be used the once until the paint sets.

Thank you for choosing Simply Shutter products.